



# **Installation and User Manual Green Point RT 1-3kVA pf1**

**KEEP FOR FUTURE REFERENCE**

for the entire life of the appliance

All rights reserved.

The information in this document is subject to change without notice.

## Publish statement

Thank you for purchasing this series UPS.

This series UPS is an intelligent, single phase in single phase out, high frequency online UPS designed by our R&D team who is with years of designing experiences on UPS. With excellent electrical performance, perfect intelligent monitoring and network functions, smart appearance, complying with EMC and safety standards, The UPS meets the world's advanced level.

Read this manual carefully before installation.

This manual provides technical support to the operator of the equipment.

## Table of Contents

<b>1. Important Safety Warning</b>	<b>4</b>
1-1 Transportation	4
1-2 Preparation	4
1-3 Installation	4
1-4 Operation	5
1-5 Maintenance, service and faults	5
1-6 Symbols used in this guide	6
<b>2. Installation and setup</b>	<b>6</b>
2-1 Unpack checking	6
2-2 Real panel view	7
2-3 Installing the UPS	8
2-4 UPS start up and turn off	16
2-5 Configuring Battery Settings	17
2-6 LCD control panel	18
2-7 Setup the UPS	19
<b>3. Operations</b>	<b>20</b>
3-1 Button operation	20
3-2 LCD display	21
3-3 UPS setting	25
3-4 Operating Mode Description	28
3-5 Operational Status and Mode(s)	29
3-6 Alarm or Fault reference code	30
<b>4. Troubleshooting</b>	<b>31</b>
<b>5. Storage and Maintenance</b>	<b>34</b>
<b>6. Options</b>	<b>34</b>
<b>7. Specification</b>	<b>37</b>

# 1. Important Safety Warning

## Important safety instructions – Save these instructions

Please comply with all warnings and operating instructions in this manual strictly. Save this manual properly and carefully read the following instructions before installing the unit. Do not operate this unit before reading through all safety information and operating instructions carefully.

There exists dangerous voltage and high temperature inside the UPS. During the installation, operation and maintenance, please abide the local safety instructions and relative laws, otherwise it will result in personnel injury or equipment damage. Safety instructions in this manual act as a supplementary for the local safety instructions. Our company will not assume the liability that caused by disobeying safety instructions.

### 1-1 Transportation

- Please transport the UPS system only in the original package to protect against shock and impact.

### 1-2 Preparation

- Condensation may occur if the UPS system is moved directly from cold to warm environment. The UPS system must be absolutely dry before being installed. Please allow at least two hours for the UPS system to acclimate the environment.
- Do not install the UPS system near water or in moist environments.
- Do not install the UPS system where it would be exposed to direct sunlight or near heater.
- Do not block ventilation holes in the UPS housing.

### 1-3 Installation

- Do not connect appliances or devices which would overload the UPS system (e.g. laser printers) to the UPS output sockets.
- Place cables in such a way that no one can step on or trip over them.
- Do not connect domestic appliances such as hair dryers to UPS output sockets.
- The UPS can be operated by any individuals with no previous experience.
- Connect the UPS system only to an earthed shockproof outlet which must be easily accessible and close to the UPS system.
- Please use only VDE-tested, CE-marked mains cable (e.g. the mains cable of your computer) to connect the UPS system to the building wiring outlet (shockproof outlet).
- Please use only VDE-tested, CE-marked power cables to connect the loads to the UPS system.
- When installing the equipment, it should ensure that the sum of the leakage current of the UPS and the connected devices does not exceed 3.5mA.

## 1-4 Operation

- Do not disconnect the mains cable on the UPS system or the building wiring outlet (shockproof socket outlet) during operations since this would cancel the protective earthing of the UPS system and of all connected loads.
- The UPS system features its own, internal current source (batteries). The UPS output sockets, or output terminals block may be electrically live even if the UPS system is not connected to the building wiring outlet.
- In order to fully disconnect the UPS system, first press the OFF/Enter button to disconnect the mains.
- Prevent no fluids or other foreign objects from inside of the UPS system.

## 1-5 Maintenance, service and faults

- The UPS system operates with hazardous voltages. Repairs may be carried out only by qualified maintenance personnel.
- **Caution** - risk of electric shock. Even after the unit is disconnected from the mains (building wiring outlet), components inside the UPS system are still connected to the battery and electrically live and dangerous.
- Before carrying out any kind of service and/or maintenance, disconnect the batteries and verify that no current is present, and no hazardous voltage exists in the terminals of high capability capacitor such as BUS-capacitors.
- Only persons are adequately familiar with batteries and with the required precautionary measures may replace batteries and supervise operations. Unauthorized persons must be kept well away from the batteries.
- **Caution** - risk of electric shock. The battery circuit is not isolated from the input voltage. Hazardous voltages may occur between the battery terminals and the ground. Before touching, please verify that no voltage is present!
- Batteries may cause electric shock and have a high short-circuit current. Please take the precautionary measures specified below and any other measures necessary when working with batteries:
  - remove wristwatches, rings and other metal objects
  - use only tools with insulated grips and handles.
- When changing batteries, install the same number and same type of batteries.
- Do not attempt to dispose of batteries by burning them. This could cause battery explosion.
- Do not open or destroy batteries. Escaping electrolyte can cause injury to the skin and eyes. It may be toxic.
- Please replace the fuse only with the same type and amperage in order to avoid fire hazards.
- Do not dismantle the UPS system.

## 1-6 Symbols used in this guide



**WARNING!**

Risk of electric shock



**CAUTION!**

Read this information to avoid equipment damage

## 2. Installation and setup

**NOTE:** Before installation, please inspect the unit. Be sure that nothing inside the package is damaged. Please keep the original package in a safe place for future use.

### 2-1 Unpack checking


- Don't lean the UPS when moving it out from the packaging.
- Check the appearance to see if the UPS is damaged or not during the transportation, do not switch on the UPS if any damage found. Please contact the dealer right away.
- Check the accessories according to the packing list and contact the dealer in case of missing parts.

It includes:


- (1) UPS user's guide
- (2) Software Suite CD
- (3) USB cable
- (4) Power cord (Input and output)
- (5) RS232 cable

## 2-2 Real panel view


**1KVA(S/H):**



**2KVA(S/H):**



**3KVA(S/H):**



1. Output receptacles (10A)
2. Battery Terminal
3. SNMP intelligent slot (option)
4. Network/Fax/Modem Surge Protection (option)
5. RS-232 communication port
6. AC input receptacle
7. Input circuit breaker
8. EPO (option)
9. USB (option)
10. Output receptacle (16A)

## 2-3 Installing the UPS

### • Rackmount installation

The Rackmount cabinet comes with all the hardware required for installation in a standard EIA or JIS seismic Rackmount configuration with square and round mounting holes. The rail assemblies adjust to mount in 19" racks with a distance from front to rear around 70~76 cm (27 to 30 inches) deep.

#### CAUTION



- The cabinet is heavy. Removing the cabinet from its carton requires a minimum of two people.
- If installing optional EBP(S), make sure to install the EBP(S) directly below the UPS so that all wiring between the cabinets is installed behind the front covers and inaccessible to users.

**NOTE** Mounting rails are required for each individual cabinet

(1) To install the rail kit

- Assemble the left and right rails to the rear rails as shown in Figure 1. Do not tighten the screws.

Adjust each rail size for the depth of your rack.




Figure 1 Securing the Rails

- Select the proper size in the rack for positioning the UPS (see Figure 2). The rail occupies four positions on the front and rear of the rack.
- Tighten four M5 Umbrella Nuts in the side of rail assembly (see Figure 1).
- Fix one rail assembly to the front of the rack with one M5×12 pan-head screw and one M5 cage nut. Using two M5 cage nuts and two M5×12 pan-head screws, to fix the rail assembly to the rear of the rack.






Figure 2 Fixing the Rails

- e) Repeat Steps 3 and 4 for the other rail assembly.
- f) Tighten the four butterfly nuts in the middle of each rail assembly.
- g) If installing optional cabinets, repeat Step 1 through Step 6 for each rail kit.
- h) Place the UPS on a flat, stable surface with the front of the cabinet facing to you.
- i) Align the mounting brackets with the screw holes on each side of the UPS and fix with the supplied M4×8 flat-head screws (see Figure 3)




Figure 3 Installing the Mounting Brackets

- j) If installing optional cabinets, repeat Step 8 and 9 for each cabinet.
- k) Slide the UPS and any other optional cabinets into the rack.
- l) Secure the front of the UPS to the rack using one M5×12 pan-head screws and one M5 cage nuts on each side (see Fig. 4). Install the bottom screw on each side through the bottom hole of mounting bracket and the bottom hole of the rail.

Repeat for any optional cabinets.




Figure 4 Securing the Front of the Cabinet

- m) Continue to the following section, “Rackmount Wiring Installation”.

## (2) Rackmount Wiring Installation

- a) Installing the UPS, including connecting the UPS internal batteries
- b) Connecting any Optional EBP(S)

## • To install the UPS

**NOTE** Do not make unauthorized changes to the ups; otherwise, damage may occur to your equipment and void your warranty.

**NOTE** Do not connect the ups power cord to utility until after installation is completed.

- a) Remove the front cover of each UPS

Press the cover side with LCD display, hold the other side and quickly extract it, then extract the other side with display. (see Fig. 5)

**NOTE** A ribbon cable connects the LCD control cover to the UPS. Do not pull on the cable or disconnect it.

When remove the cover, operate as the following right Figure shows instead of the left one. (see Fig. 5)




Figure 5 Extract UPS front cover



**CAUTION**

*A small amount of arcing may occur when connecting the internal batteries. This is normal and will not harm personnel. Connect the cables quickly and firmly*

- b) Connect the internal battery connector (see Figure 6)

Connect red to red, press the connector tightly together to ensure a proper connection.

- c) If you are installing EBPS, see the following section, "Connecting the EBP(s)," before continuing with the UPS installation.




Figure 6 Connecting the UPS Internal Batteries

- d) Replace the UPS front cover.

To replace the cover, verify that the ribbon cable is protected and (if EBPS are installed) the EBP cable is routed through the knockout on the bottom of the cover.

Put the front cover hooks of side with display to the cover port, put another side to the other two ports, then press it until the cover and the chassis are combined tightly.




Figure 7

- e) If you are installing power management software, connect your computer to one of the communication ports or optional connectivity card. For the communication ports, use an appropriate cable.
- f) If your rack has conductors for grounding or bonding of ungrounded metal parts, connect the ground cable (not supplied) to the ground bonding screw. See "Rear Covers" for the location of the ground bonding screw for each model.
- g) If an emergency power-off (disconnect) switch is required by local codes, see Remote Emergency Power-off" (REPO) to install the REPO switch before powering on the UPS.
- h) Continue to "UPS Start up".

## • Connecting the EBP(s)

(1) To install the optional EBP(s) for a UPS

- a) Remove the front cover of each EBP and UPS (see Figure 8).

It is the same with the installation of the front cover. (Refer "To install the UPS")




Figure 8 Removing the EBP Front Cover

- b) On the bottom of the UPS front cover, remove the EBP cable knockout (see gFig. 9).




Figure 9 Removing the UPS Cable Knockout

- c) For the bottom (or only) EBP, remove the EBP cable knockout on the top of the EBP front cover. See Figure 10 for the location of the top EBP cable knockout.
- d) If you are installing more than one EBP, for each additional EBP remove the EBP cable knockout on the top and bottom of the EBP front cover. See Figure 10 for the location of the EBP cable knockouts.



### CAUTION

*A small amount of arcing may occur when connecting an EBP to the UPS. This is normal and will not harm personnel. Insert the EBP cable into the UPS battery connector quickly and firmly.*

- e) Plug the EBP cable(s) into the battery connector(s) as shown in Figure 10. Up to four EBPS may be connected to the UPS. Connect black to black. Press the connector tightly together to ensure a proper connection.

To connect a second EBP, unclip the EBP connector on the first EBP and pull gently to extend the wiring to the EBP connector on the second EBP. Repeat for any additional EBPs.

- f) Verify that the EBP connections are tight and the adequate bend radius and strain relief exist for each cable.




Figure 10 Typical EBP Installation

- g) Replace the EBP front cover.

To replace the cover, verify that the EBP cables are routed through the EBP cover knockouts, cover connects with the cover hook near the left side of the EBP cabinet. Repeat for each additional EBP.

It is the same with the installation of the front cover. (Refer" to install the UPS")

- h) Verify that all wires connected between the UPS and EBP(s) are installed behind the front covers and not accessible to users.

- i) Return to Step4 to continue the UPS installation.

## ● Rackmount converted to Tower Installation

(1) Rackmount converted to Tower plastic base installation

- ① Two plastic base brackets
- ② Flatten it after intercrossing

Intercross as following Figure:





Figure 11 plastic base installation

- ③ If an EBP is needed to be placed in the middle, the assembly of plastic base is similar (Figure 11). The difference is that two 1U plastic base extended boards are added in the middle. (as the following shows)









Figure 12 increase EBP plastic base installation

- The installation between UPS and EBPS can be referred to **Fig.13**






Figure 13 The installation for UPS and battery box




Figure 14 Long backup external battery connection

- a) Install the base, then place the RT UPS on the base one by one as Fig.13 shows.
- b) The cover installation and cable connection of the UPS and EBPS are the same as RT. (To install the optional EBP(s) for a UPS)

## 2-4 UPS start up and turn off

### • Startup operation

- (1) Turn on the UPS in line mode

**NOTE** Verify that the total equipment ratings do not exceed the UPS capacity to prevent an overload alarm.

- a) Once mains power is plugged in, the UPS will charge the battery, at the moment, the LCD shows that the output voltage is 220, which means the UPS automatically start the inverter. If



it is expected to change to bypass model, you can Press “OFF” key.

- b) Press and hold the ON key for more than half a second to start the UPS, then it will start the inverter.
  - c) Once started, the UPS will perform a self-test function, LED will light and go out circularly and orderly. When the self-test finishes, it will come to line mode, the corresponding LED lights, the UPS is working in line mode.
- (2) Turn on the UPS by DC without mains power
- a) When mains power is disconnected, press and hold the ON key for more than half a second to start UPS.
  - b) The operation of the UPS in the process of start is almost the same as that when mains power is in. After finishing the self-test, the corresponding LED lights and the UPS is working in battery mode.

## • Turn off operation

- (1) Turn off the UPS in line mode
- a) Press and hold the OFF key for more than half a second to turn off the UPS and inverter.
  - b) After the UPS shutdown, the LEDs go out and there is no output. If output is needed, you can set bps “ON” on the LCD setting menu.
- (2) Turn off the UPS by DC without mains power
- a) Press and hold the OFF key for more than half a second to turn off the UPS.
  - b) When turning off the UPS, it will do self-testing firstly. The LEDs light and go out circularly and orderly until there is no display on the cover.

## 2-5 Configuring Battery Settings


### • Set the UPS for the number of EBPs installed

To ensure maximum battery runtime, configure the UPS for the correct number of EBPs, refer to Table 8 for the appropriate setting of battery numbers and type. Use the up and down scroll keys to select the number of battery strings according to your UPS configuration:

All UPS and EBP Cabinets	Number of Battery Strings
UPS only (internal batteries)	1 (default)
UPS+1EBP	3
UPS+2EBPs	5





UPS+3EBPs	7
UPS+4EBPs	9
<b>NOTE:</b> The UPS contains one battery string; each EBP contains two battery strings.	

## 2-6 LCD control panel



LCD control panel introduction

- (1) LED (from top to bottom: “alarm”, “bypass”, “battery”, “inverter”);
- (2) On-Line UPS LCD display; (3) Buttons-FUNC button/OFF button/On button.

Indicator	Status	Description
 Red	On	The UPS has an active alarm or fault.
 Yellow	On	The UPS is in Bypass mode. The UPS is operating normally on bypass during High Efficiency operation.
 Yellow	On	The UPS is on Battery mode.
 Green	On	The UPS is operating normally on Online.
<p><b>NOTE</b> When power on or startup, these indicators will turn on and off sequentially.</p> <p><b>NOTE</b> On different operation modes, these indicators will indicate differently.</p>		

## 2-7 Setup the UPS

### Step 1: UPS input connection

Plug the UPS into a two-pole, three-wire, grounded receptacle only. Avoid using extension cords.

- For 208/220/230/240VAC models: The power cord is supplied in the UPS package.

### Step 2: UPS output connection

- For socket-type outputs, simply connect devices to the outlets.
- For terminal-type input or outputs, please follow below steps for the wiring configuration:
  - Remove the small cover of the terminal block
  - Suggest using AWG14 or 2.1mm<sup>2</sup> power cords for 3KVA (220/230/240VAC models).
  - Upon completion of the wiring configuration, please check whether the wires are securely affixed.
  - Put the small cover back to the rear panel.


### Step 3: Communication connection

**Communication port:**

**USB port**



**RS-232 port**



**Intelligent slot**



To allow for unattended UPS shutdown/start-up and status monitoring, connect the communication cable one end to the USB/RS-232 port and the other to the communication port of your PC. With the monitoring software installed, you can schedule UPS shutdown/start-up and monitor UPS status through PC.

The UPS is equipped with intelligent slot perfect for either SNMP or Relay card. When installing either SNMP or Relay card in the UPS, it will provide advanced communication and monitoring options.

**NOTE: USB port and RS-232 port can't work at the same time.**

## Step 4: Turn on the UPS

Press the ON button on the front panel for two seconds to power on the UPS.



**Note:** The battery charges fully during the first five hours of normal operation. Do not expect full battery run capability during this initial charge period.




## Step 5: Install software

For optimal computer system protection, install UPS monitoring software to fully configure UPS shutdown. You may insert provided CD into CD-ROM to install the monitoring software.

## 3. Operations

### 3-1 Button operation


Button	Function
ON Button 	<ul style="list-style-type: none"> <li>➤ Turn on the UPS: Press and hold ON button for at least 2 seconds to turn on the UPS.</li> <li>➤ Choosing different value: When the UPS enters the setting mode, press this button to choose the different value what you want.</li> <li>➤ Out of bypass mode: when the UPS enter to bypass mode, press and hold this button it will switch to normal mode.</li> </ul>
OFF Button 	<ul style="list-style-type: none"> <li>➤ Turn off the UPS: Press and hold this button at least 2 seconds to turn off the UPS in battery mode. UPS will be in standby mode under power normal or transfer to Bypass mode if the Bypass enable setting by pressing this button.</li> <li>➤ Down key: Press this button to display next selection in UPS setting mode.</li> <li>➤ Exit setting mode: Press this button to confirm selection and exit setting mode when LCD display the last selection in UPS setting mode.</li> </ul>





	<ul style="list-style-type: none"> <li>➤ Switch to bypass mode: When the main power is normal, press this button in 1 seconds. Then UPS will enter to bypass mode. This action will be ineffective when the input voltage is out of acceptable range.</li> </ul>
<p>FUNC/Rotate/Mute Button</p> 	<ul style="list-style-type: none"> <li>➤ Switch LCD message: Press this button to change the LCD message for input voltage, input frequency, battery voltage, output voltage and output frequency etc.</li> <li>➤ Rotate Key: After the UPS turn on, continue to press the button for 15 seconds and then the LCD screen begin to rotate. Again and it will be return!</li> <li>➤ Mute the alarm: When the UPS is on battery mode, press and hold this button for at least 5 seconds to disable or enable the alarm system. But it's not applied to the situations when warnings or errors occur.</li> <li>➤ Up key: Press this button to display previous selection in UPS setting mode.</li> <li>➤ Switch to UPS self-test mode: Press and hold this button for 2 seconds to enter UPS self-testing while in AC mode.</li> </ul>
<p>FUNC + OFF Button ( + )</p>	<ul style="list-style-type: none"> <li>➤ Setting mode: Press and hold these buttons in the same moment for 5 seconds to enter UPS setting mode.</li> </ul>




## 3-2 LCD display

### Part one: Rack display

There are 8 interfaces available in the LCD display.

Item	Interface Description	Content Displayed
01	Input voltage	






02	Battery voltage	
03	Output voltage	
04	Load	
05	Environment Temperature	

06	Firmware Version & UPS model	
07	CODE (Operational status and mode)	
08	Alarm Code (Warning Message) All alarm codes are present when abnormal behavior(s) occur(s)	




## Part two: Tower display

- After the UPS turn ON, continue to press the function key for 10 seconds, the LCD screen begin to rotate.
- LCD display with rotation function and after rotating display information content is constant, the LCD display information only display the direction and pattern of change.
- LCD display after rotation, and then shut down, to boot, the LCD screen saved with rotating state.

Item	Interface Description	Content Displayed
------	-----------------------	-------------------

01	Input voltage	 <p>On-Line UPS <span style="color: green;">■</span> <span style="color: yellow;">■</span> <span style="color: red;">■</span> <span style="color: red;">■</span> ~  </p> <p>INPUT 223 VAC 50.0 Hz</p>
02	Battery voltage	 <p>On-Line UPS <span style="color: green;">■</span> <span style="color: yellow;">■</span> <span style="color: red;">■</span> <span style="color: red;">■</span> ~  </p> <p>BATTERY 22.0 V </p>
03	Output voltage	 <p>On-Line UPS <span style="color: green;">■</span> <span style="color: yellow;">■</span> <span style="color: red;">■</span> <span style="color: red;">■</span> ~  </p> <p>Output 223 VAC 50.0 Hz</p>
04	Load	 <p>On-Line UPS <span style="color: green;">■</span> <span style="color: yellow;">■</span> <span style="color: red;">■</span> <span style="color: red;">■</span> ~  </p> <p>Load 1.1 KW 1.1 KVA </p>
05	Environment Temperature	 <p>On-Line UPS <span style="color: green;">■</span> <span style="color: yellow;">■</span> <span style="color: red;">■</span> <span style="color: red;">■</span> ~  </p> <p>TEMP 33 °C</p>



06	Firmware Version & UPS model	
07	CODE (Operational status and mode)	
08	Alarm Code (Warning Message) All alarm codes are present when abnormal behavior(s) occur(s)	




### 3-3 UPS setting





The UPS has setting functions. These user settings can be done under any kind of UPS working mode. The setting will take effect under certain conditions. The table below describes how to set the UPS.













The setting function is controlled by 3 buttons (FUNC/Up▲, OFF/Down▼, ON/Enter↻): FUNC/Up▲ + OFF/Down▼ --- goes into the setting page, ON/Enter↻ --- value adjustment; FUNC/Up▲ & OFF/Down▼ --- for choosing different pages.

After the UPS turns ON, press buttons "▲&▼" for 5 seconds and then goes into the setting interface page.



Setting saving method: After setting the project parameters, press the down button ▼ until you enter the last page of the setting, and then press the down button ▼ to automatically exit the current setting mode, and it will take effect after powering off and saving in battery mode.





Item	Settings	Content display
01	<p>Mode setting</p> <p>Press Enter button ↵ to change the setting (NOR or ECO or CF). Press UP button ▲ to select the previous setting. Press DOWN button ▼ to select the next setting.</p>	
02	<p>Output voltage setting</p> <p>Press Enter button ↵ to change the setting (208, 220, 230, 240). Press UP button ▲ to select the previous setting. Press DOWN button ▼ to select the next setting.</p>	
03	<p>Frequency setting</p> <p>Press Enter button ↵ to change the setting (50 or 60Hz). Press UP button ▲ to select the previous setting. Press DOWN button ▼ to select the next setting.</p>	

04	<p>EOD point voltage setting (one power-off set point) Press the selection button P to select different setting values (1.75/1.84/1.92) Default setting 184 (1.84V /cell) Press the up button ▲ to select the previous option. Press the down button ▼ to select the next option.</p>	
05	<p>EOD voltage setting Press Func button to change the setting (160/167/175/180.) default setting: 175(1.75V /cell) Press UP button ▲ to select the previous setting. Press DOWN ▼ button to select the next setting.</p>	
06	<p>Bypass voltage upper limit setting Press Enter button ↵ to change the setting (The bypass voltage upper limit range is 230-264Vac). Press UP button ▲ to select the previous setting. Press DOWN button ▼ to select the next setting.</p>	
07	<p>Bypass voltage lower limit setting Press Enter button ↵ to change the setting (The bypass voltage lower limit range is 176-220Vac). Press UP button ▲ to select the previous setting. Press DOWN button ▼ to select the next setting.</p>	

08	<p>Mute setting</p> <p>Press Enter button  to change the setting (ON or OFF). Press UP button  to select the previous setting. Press DOWN button  to save and exit the setup.</p>	
09	<p>BYPASS enable/disable setting</p> <p>Press Enter button  to change the setting (ON or OFF). Press UP button  to select the previous setting. Press DOWN button  to save and exit the setup.</p>	
10	<p>Generator mode setting</p> <p>Press Enter button  to change the setting (ON or OFF). The factory default is: OFF, need to be manually set after the generator is manually connected. Press the up button  to select the previous option. Press DOWN button  to save and exit the setup.</p>	

### 3-4 Operating Mode Description

Mode	Description	Indicator
Line Mode	The inverter green LED is on. When input AC mains is in line with the working conditions, UPS will work in line mode, charge the battery and protect the load.	
Battery Mode	Both the inverter green LED and battery yellow LED is on, and the buzzer beeps once per 4 seconds. When the mains power down or instable, UPS will turn to Battery Mode at once. If the mains recover, the UPS will transfer to line mode.	

	<p>If battery voltage low alarm activates, the indicator of battery LED flashes. If battery voltage reaches low limit, UPS will turn off to protect the battery. UPS will auto-restart when the mains recover.</p> <p>⚠ <b>NOTE:</b> The backup time of Battery Mode is subject to the load and EBP numbers.</p>	
Bypass Mode	<p>The bypass yellow LED is on.</p> <p>Bypass tolerance can be set by Bypass voltage limit setting.</p> <p>Under below conditions, the UPS will transfer to bypass mode:</p> <ul style="list-style-type: none"> <li>● BPS on set by user through Mode setting and set to ECO Mode.</li> <li>● Press the OFF button when online Mode.</li> <li>● Overload online Mode.</li> </ul> <p>⚠ <b>NOTE:</b> When in bypass mode, the load is not protected.</p>	
ECO Mode	<p>Both the inverter green LED and bypass yellow LED is on.</p> <p>When ECO enabled and the utility is in range, the UPS will work on ECO Mode. If the utility is out of ECO range but still in Line range, the UPS will transfer to Line Mode.</p> <p>Utility tolerance of ECO Mode can be set.</p>	
Standby mode	<p>All LEDs turn off</p> <p>UPS is powered off and no output supply power, but still can charge batteries.</p>	
Fault Mode	<p>When the UPS has fault. The warning red LED is on and the buzzer beeps.</p> <p>The UPS will turn to fault mode. If you turn on the UPS without the Fan and the LCD display fault codes. At the moment, you can press the OFF key to shut down the UPS when the mains power down. Confirm that there is no serious fault to turn on the UPS.</p> <p>⚠ <b>NOTE:</b> As for corresponding information of the fault code, please refer to alarm or fault reference code.</p>	

### 3-5 Operational Status and Mode(s)

item	Content Displayed
2	Standby Mode
3	No Output
4	Bypass Mode
5	Utility Mode
6	Battery Mode

7	Battery Self-diagnostics
8	Inverter is starting up
9	ECO Mode
10	EPO Mode
11	Maintenance Bypass Mode
12	Fault Mode
13	Generator Mode

### 3-6 Alarm or Fault reference code

Event log	UPS Alarm Warning	Buzzer	LED
1	Rectifier Fault	Beep continuously	Fault LED lit
2	Inverter fault (Including Inverter bridge is shorted)	Beep continuously	Fault LED lit
9	Fan fault	Beep continuously	Fault LED lit
12	Self-test fault	Beep continuously	Fault LED lit

13	Battery Charger fault	Beep continuously	Fault LED lit
15	DC Bus over voltage	Beep continuously	Fault LED lit
16	DC Bus below voltage	Beep continuously	Fault LED lit
17	DC bus unbalance	Beep continuously	Fault LED lit
18	Soft start failed	Beep continuously	Fault LED lit
19	Rectification model Over Temperature	Twice per second	Fault LED lit
20	Inverter model Over Temperature	Twice per second	Fault LED lit
26	Battery over voltage	Once per second	Fault LED blinking
27	Mains Input reverse	Once per second	Fault LED blinking
28	Bypass Input reverse	Once per second	Fault LED blinking
29	Output Short-circuit	Once per second	Fault LED blinking
30	Input current limit	Once per second	Fault LED blinking
31	Bypass over current	Once per second	BPS LED blinking
32	Overload	Once per second	INV or BPS LED blinking
33	No battery	Once per second	Battery LED blinking
34	Battery under voltage	Once per second	Battery LED blinking
35	Battery low pre-warning	Once per second	Battery LED blinking
36	Overload time out	Once per 2 seconds	Fault LED blinking
37	DC component over limit.	Once per 2 seconds	INV LED blinking
39	Mains volt. Abnormal	Once per 2 seconds	Battery LED lit
40	Mains freq. abnormal	Once per 2 seconds	Battery LED lit
41	Bypass Not Available		BPS LED blinking
42	Bypass out of tracking range		BPS LED blinking
45	EPO Enable	Beep continuously	Fault LED lit


## 4. Troubleshooting

If the UPS system does not operate correctly, please solve the problem by using the table below and the Trouble Shooting Chart.

Symptom	Possible cause	Remedy
---------	----------------	--------

No indication and alarm even though the mains is normal.	The AC input power is not connected well.	Check if input power cord firmly connected to the mains.
	The AC input is connected to the UPS output.	Plug AC input power cord to AC input correctly.
Alarm code is shown as "33" and battery led blinking.	The external or internal battery is incorrectly connected.	Check if all batteries are connected well.
Alarm code is shown as "26" and battery led blinking.	Battery voltage is too high, or the charger is fault.	Contact your dealer.
Alarm code is shown as "34" and battery led blinking	Battery voltage is too low, or the charger is fault.	Contact your dealer.
Alarm code is shown as "32" and INV or BYPASS led blinking.	UPS is overload	Remove excess loads from UPS output.
Alarm code is shown as "29" and FAULT led light.	The UPS shut down automatically because short circuit occurs on the UPS output.	Check output wiring and if connected devices are in short circuit status.
Alarm code is shown as "9" and FAULT led light.	Fan fault.	Contact your dealer.
Alarm code is shown as "01,02, 15,16,17,18"	A UPS internal fault has occurred.	Contact your dealer.
Battery backup time is shorter than nominal value	Batteries are not fully charged	Charge the batteries for at least 5 hours and then check capacity. If the problem still persists, consult your dealer.
	Batteries defect	Contact your dealer to replace the battery.





Trouble Shooting Chart

## 5. Storage and Maintenance

### • Operation

The UPS system contains no user-serviceable parts. If the battery service life (3~5 years at 25°C ambient temperature) has been exceeded, the batteries must be replaced. In this case, please contact your dealer.



Be sure to deliver the spent battery to a recycling facility or ship it to your dealer in the replacement battery packing material.

### • Storage

Before storing, charge the UPS 5 hours. Store the UPS covered and upright in a cool, dry location. During storage, recharge the battery in accordance with the following table:

Storage Temperature	Recharge Frequency	Charging Duration
-25°C - 40°C	Every 3 months	1-2 hours
40°C - 45°C	Every 2 months	1-2 hours

## 6. Options


**SNMP card:** internal SNMP (options)

- ◆ Loosen the 2 torque screws (on each side of the card).
- ◆ Carefully insert the SNMP card and lock the screws

The slot called SNMP supports the MEGAtec protocol. We advise that Net AgentII-3 port is also a tool to remotely monitor and manage any UPS system

NetAgentII-3Ports supports the Modem Dial-in (PPP) function to enable the remote control via the internet when the network is unavailable.

In addition to the features of a standard NetAgent Mini, NetAgent II has the option to add Net Feeler Lite to detect temperature, humidity, smoke and security sensors. Thus, making NetAgent II a versatile management tool. NetAgent II also supports multiple languages and is set up for web-based auto language detection.



Typical topology of the UPS Network Management

### Relay card (options)

Mini dry contact card is used for providing the interface for UPS peripheral monitoring. The contact signals can reflect UPS running status. The card is connected to peripheral monitoring devices via terminal board to facilitate the effective monitoring of the real-time status of UPS and timely feedback the status to monitor when abnormal situation occurs (such as UPS failure, mains interruption, UPS bypass and ect.). It is installed in the intelligent slot of the UPS.

The relay card includes 6 output ports and one input port. Please refer to the following table for detail.



Product appearance



Pins definition of connecting terminal on the board

Terminal No.	Terminal function	Terminal No.	Terminal function
1	Common source	9	Bypass active NO
2	UPS on NO	10	Bypass active NC
3	AC fail NO	11	UPS fail NO
4	AC fail NC	12	UPS fail NC
5	Batt low NO	CN4-1	Remote shutdown
6	Batt low NC	CN4-2	GND
7	UPS alarm NO		
8	UPS alarm NC		

### Relay card electrical parameter

	max	Type
Relay card contact	(Max Switched Voltage) AC:120V DC:24V	AC:120V
		DC:5~12V
	(Max Switched Current) AC:1A DC:1A	AC:1A
		DC:1A

### Emergency Power-off (EPO) (options)

EPO is used to shut down the UPS from a distance. This feature can be used for shutting down the load and the UPS by thermal relay, for instance in the event of room overtemperature. When EPO is activated, the UPS shuts down the output and all its power converters immediately. The UPS remains on to alarm the fault.




EPO Connections

NOTE: Depending on user configuration, the pins must be shorted or opened to keep the UPS running. To restart the UPS, reconnect (re-open) the EPO connector pins and turn on the UPS manually. Maximum resistance in the shorted loop is 10 ohm.

Always test the EPO function before applying your critical load to avoid accidental load loss. Leave the EPO connector installed onto the EPO port of the UPS even if the EPO function is not needed.

### Load Segments (options)

Load segments are sets of receptacles that can be controlled by power management software or through the display, providing an orderly shutdown and startup of your equipment. For example, during a power outage, you can keep critical equipment running while you turn off other equipment. This feature allows you to save battery power. Each UPS has two load segments:



Load Segment 1: The power shedding battery voltage of this segment can be set by LCD.

Load Segment 1: The power shedding battery end of discharge (EOD).

## 7. Specification

MODEL		1KVA	2KVA	3KVA
PHASE		Single phase with ground		
Capacity (VA/Watts)		1000VA /1000W	2000VA / 2000W	3000VA / 3000W
INPUT				
Nominal voltage		208/220/230/240VAC		
Operating voltage range (Ambient Temp. <40°C)	Low line transfer	176Vac±5% @100%-50% load; 110Vac±5% @50%-0% load;		
	Low line comeback	186Vac±5% @100%-50% load; 120Vac±5% @50%-0% load;;		
	High line transfer	264Vac±5% @100%-50% load; 300Vac±5% @50%-0% load;		
	High line comeback	254Vac±5% @100%-50% load; 290Vac±5% @50%-0% load;		
Operating frequency range**		40-70Hz		
Power factor		0.99@100% load (Nominal Input Voltage)		
Bypass voltage range		<b>Bypass high voltage point</b> <b>230-264:</b> setting the high voltage point in LCD from 230Vac to 264Vac. (Default: 264Vac) <b>Bypass low voltage point</b> <b>176-220:</b> setting the low voltage point in LCD from 176Vac to 220Vac. (Default: 176Vac)		
Generator input		Support		
OUTPUT				
Output voltage*		208/220/230/240Vac		
Power factor		1.0		
Voltage regulation		±1%		
Frequency	Line Mode (synchronized range)	46-54Hz or 56-64Hz		
	Bat. Mode	(50/60±0.1) Hz		
Crest factor		3:1		
Harmonic distortion (THDv)		≤3% THD with linear load ≤5% THD with non linear load		
Waveform		Pure Sinewave		
Transfer time	AC mode <->Batt. mode	Zero		
	Inverter <-> bypass	4ms (Typical)		
Efficiency		88% (AC mode) 85% (DC mode)	90% (AC mode) 86% (DC mode)	90% (AC mode) 87% (DC mode)

BATTERY			
Battery Type	12V9AH	12V9AH	12V9AH
Numbers	2	4	6
Typical recharge time (standard model)	4 hours recover to 90% capacity (Typical)		
Charging voltage	27.4 VDC ±1%	54.7 VDC ±1%	82.1 VDC ±1%
Charge current	1A/2A (2A by default)	1A/2A (2A by default)	1A/2A (2A by default)
SYSTEM FEATURES			
Overload	Line Mode	105%~125%: UPS transfer to bypass after 1minute when the utility is normal 125%~130%: UPS transfer to bypass after 30 seconds when the utility is normal >130%: UPS transfer to bypass immediately when the utility is normal	
Short Circuit		Hold Whole System	
Overheat		Line Mode: Switch to Bypass; Backup Mode: Shut down UPS immediately	
Low battery voltage		Alarm and Switch off	
EPO (optional)		Shut down UPS immediately	
Audible & Visual alarms		Line Failure, Battery Low, Overload, System Fault	
Communication interface		USB (or RS232), SNMP card(optional), Relay card (optional)	
ENVIRONMENTAL			
Operating temperature		0℃~40℃	
Storage temperature		-25℃~55℃	
Humidity range		20-90 % RH @ 0- 40℃ (non-condensing)	
Altitude		< 1500m	
Noise level		Less than 55dBA at 1 Meter	
PHYSICAL			
Dimension W×D×H (mm)	440*325* 86.5	440*460*86.5	440*600*86.5
Net Weight (kg)	11.3	19.5	26.2
STANDARDS			
Safety		IEC/EN62040-1, IEC/EN60950-1	
EMC		IEC/EN62040-2, IEC61000-4-2, I EC61000-4-3, IEC61000-4-4, IEC61000-4-5, IEC61000-4-6, IEC61000-4-8	

\* Derate to 80% of capacity when the output voltage is adjusted to 208VAC

\*\* Derate to 75% of capacity when the Input voltage frequency out of range(50/60 $\pm$ 4Hz)

\*\*\* Product specifications are subject to change without further notice.